



NTG Motor Services Limited

282 - 284 Bramford Road Ipswich Suffolk IP1 4AY

Tel: ++44 (0)1473 - 406031 & 406032

Fax: ++44 (0)1473 - 743133 Email: sales@mgbits.com

www.mgbits.com

www.bmcfarina.com

Directors: M.Green P.Banyard

Company Reg.No. 1262476

V.A.T.Reg. No. 289 5422 17

Fitting Instructions for Steering Wheel Cover X180F

1. Fit the leather cover over the steering wheel so that the joint is centre bottom. (6 o'clock)
2. Thread the needle and pull through enough to make a double length approx. 1 metre long
3. Tie the loose ends with a large knot.
4. Starting just to the side of one of the spokes, from the inside of the cover, push the needle through to the outside, through one of the holes made by the existing hem stitching.
5. Pass the thread over the gap between the sides and pass it under the corresponding loop of the stitching from the leather side towards the gap. (Note, do not pierce the leather but pass the thread under the existing stitching).
6. Continue to weave across the gap using every second loop of the existing stitching until the next spoke is reached. Pass the thread back to the inside and cut off the excess.
7. Pull the thread tight as you go so that the edges pull together neatly.
8. Repeat the above for the next section of wheel. The longer part of the circumference requires about 1.5 metres of doubled thread.

There are excellent video instructions on You tube - see <http://www.youtube.com/watch?v=ZvAkrMajAno>

